





Between Series Adapters



P.N.	Description
SMAM-MMCXM1-3GT50G-50	SMA Plug to MMCX Plug



P.N.	Description
NF-BF-NT3G-50	N Jack to BNC Jack



P.N.	Description
SMAF-MMCXF1-NT3G-50	SMA Jack to MMCX Jack



P.N.	Description
OS-7051-NDG	N Plug to BNC Plug



P.N.	Description
05-7324-NDG	N Plug to BNC Jack

P.N.	Description
OS-7328-NDG	N Plug to TNC Jack

P.N.	Description
NF-BM-NT3G-50	N Jack to BNC Plug

P.N.	Description
NF-TM-NT3G-50	N Jack to TNC Plug

