





**10 S - Triko Nr. 300332 ...**




**10 S - Triko Nr. 300333 ...**  
(von beiden Seiten abgleichbar)  
(adjustable from both sides)



**10 S - Triko Nr. 300320 ...**  
(10 S-Triko 20)





**10 S - Triko Nr. 300321 ...**  
(10 S-Triko 21)  
(von beiden Seiten abgleichbar)  
(adjustable from both sides)



10 S - Triko	2 / 6 pF	NP 0	Nr. .... 100	10 S - Triko	6 / 25 pF	N 750	Nr. .... 519
10 S - Triko	3 / 10 pF	NP 0	Nr. .... 101	10 S - Triko	8 / 40 pF	N 750	Nr. .... 520
10 S - Triko	3 / 15 pF	N 075	Nr. .... 203	10 S - Triko	10 / 60 pF	N 1500	Nr. .... 610
10 S - Triko	3 / 12 pF	N 470	Nr. .... 402				
10 S - Triko	4 / 20 pF	N 470	Nr. .... 405				

**10 S - Triko Nr. 300322 ...**  
(10 S-Triko 22)



**10 S - Triko Nr. 300323 ...**  
(10 S-Triko 23)

